


- All the dimensions are shown in millimetres
- Tube dia 22mm x 22mm
- Header tube dia 38mm x 38mm
- Bracket length - 50mm
- ½ inch BSP bottom opposite end connections
- Test pressure: 10 Bar
- Max working temperature: 8 Bar
- Heat output - in accordance with EN 442

Please Note:

- Please allow minimum of 100mm for valves
- Summer Element use will affect pipe centres
- The flow and return can be reversed

Premier Flat XL	Water Content (L)	Weight (KG)	Pipe Centres +/- 2mm	Fixing Centres (H) +/- 2mm	Fixing Centres (W) +/- 2mm	Height (mm)	Width (mm)
RXPS-0600300	2.1	3.5	262	472	262	600	300
RXPS-1200300	4	6.5	262	1072	262	1200	300
RXPS-1500300	5	8.1	262	1372	262	1500	300
RXPS-0800400	3	5.2	362	672	362	800	400
RXPS-0800500	3.5	6.1	462	678	462	800	500
RXPS-0800600	3.9	6.9	562	678	562	800	600
RXPS-1200400	4.5	7.8	362	1072	362	1200	400
RXPS-1200500	5.2	9	462	1072	462	1200	500
RXPS-1200600	5.9	10.3	562	1072	562	1200	600
RXPS-1500400	5.8	9.3	362	1372	362	1500	400
RXPS-1500500	6.7	12.2	462	1372	462	1500	500
RXPS-1500600	7.7	13.8	562	1372	562	1500	600
RXPS-1800400	6.9	11.8	362	1672	362	1800	400
RXPS-1800500	7.9	13.7	462	1672	462	1800	500
RXPS-1800600	9	15.6	562	1672	562	1800	600
RXPS-0600750	2	3.4	712	472	712	600	750
RXPS-06001000	3.8	6.5	932	472	932	600	1000
RXPS-0800500	3.5	6.1	462	678	462	800	500

Installation:



Step 1: Select the desired mounting position, make sure the wall is adequate to take the fixing points of the rail i.e anchor points must be securely attached to a stud or masonry.

Step 2: Loosely screw the wall support (Part 2) into the wall using the wall screw (5) and washer. Use wall plug (1) if you are fixing into masonry. Do not tighten fully.

Step 3: Manoeuvre the rail back onto the bracket and tighten with the grub screw (3).

Cleaning:

- Do not use any abrasive or chemical cleaners to clean the radiators as this will cause damage to the surface finish. Please use warm water and a damp cloth.
- Do not clean when hot.